

# DECORATIVE TOP COVER INSTALLATION

**WARNING:** Failure to position the parts in accordance with the diagrams and instructions below or failure to use only parts specifically approved for use with this heater may result in property damage or personal injury.

**NOTE:** The Loft series burners may be operated with or without the Decorative accessory options. Follow the directions below should you choose to enhance your Loft burner with any one of the available decorative options.

## OPTIONAL DECORATIVE TOP COVERS - LOFT BURNERS

Accessory Model Number	Description	Loft Burner Model Used On
DT18PB	Decorative Top Cover - Polished Black	VF(R,I)L(18,1810)
DT18SS	Decorative Top Cover - Brushed Stainless	VF(R,I)L(18,1810)
DT24PB	Decorative Top Cover - Polished Black	VF(R,I)L24
DT24SS	Decorative Top Cover - Brushed Stainless	VF(R,I)L24
DT30PB	Decorative Top Cover - Polished Black	VF(R,I)L30
DT30SS	Decorative Top Cover - Brushed Stainless	VF(R,I)L30

## DECORATIVE TOP COVER ACCESSORY INSTALLATION

The Decorative Top Cover accessory options are available for your Loft Burner. Choose the proper size Decorative Top Cover listed for use with the Loft burner assembly.

### Installation

1. Addition of the Decorative Top Cover accessory should be performed after the Loft burner has been fully installed, secured and tested for leaks. If operating the burner with a Remote Control, make sure all batteries are installed and that the Loft burner operates with the remote correctly.
2. To install, simply place the Decorative Top Cover over the top of the Loft burner and retain by folding over the side tabs to secure the Decorative Top Cover to the Loft Burner. See Figures below..

